

# **InGaAs PIN photodiodes**

G13176 series

# **Surface mount type COB (chip on board)** package

The G13176 series is a small-size near infrared detector available in a surface mount COB package. Its size is drastically reduced compared to the previous metal package type (G12180-003A/-010A). The spectral response covers a range from 0.9 to 1.7  $\mu$ m (with peak sensitivity wavelength at 1.55  $\mu$ m). This product features high sensitivity and low noise. In addition to optical communication, you can use this product for analysis, measurement, and the like. The small package makes this product suitable for integration into hand-held devices and mobile devices. The modified resin has improved the reflow resistivity as compared to the previous product (G11777-003P).

#### Features

- Low noise
- High sensitivity
- → High-speed response
- Surface mount type
- **Small size COB package**
- Low cost
- Compatible lead-free reflow soldering

# - Application

- **■** Measurement
- Analysis
- Light level monitor

## **Structure**

Parameter	Symbol	G13176-003P	G13176-010P	Unit
Window material	-	Silicone resin		
Package	-	Glass epoxy		
Photosensitive area	-	ф0.3	φ1.0	mm

#### **►** Absolute maximum ratings

Parameter	Symbol	Condition	G13176-003P	G13176-010P	Unit
Reverse voltage	VR max.		1	V	
Operating temperature	Topr	No dew condensation*1	-25 to	°C	
Storage temperature	Tstg	No dew condensation*1	-40 to +105		

Note: Handle the G13176 series with tweezers or gloves. Do not touch with bare hands. As the resin area of the G13176 series is soft, do not allow sharp or hard objects to come in contact with it, or apply external force to it.

Exceeding the absolute maximum ratings even momentarily may cause a drop in product quality. Always be sure to use the product within the absolute maximum ratings.


The G13176 series may be damaged by electrostatic discharge, etc. Be careful when using the G13176 series.

<sup>\*1:</sup> When there is a temperature difference between a product and the surrounding area in high humidity environment, dew condensation may occur on the product surface. Dew condensation on the product may cause deterioration in characteristics and reliability.


## **➡** Electrical and optical characteristics (Ta=25 °C)

Parameter	Symbol Condition	Condition	G13176-003P		G13176-010P			Unit	
		Condition	Min.	Тур.	Max.	Min.	Тур.	Max.	UIIIL
Spectral response range	λ	10% or more of the value at peak	-	0.9 to 1.7	-	-	0.9 to 1.7	-	μm
Peak sensitivity wavelength	λр		-	1.55	-	-	1.55	-	μm
Photosensitivity	S	λ=1.3 μm	0.75	0.85	-	0.75	0.85	-	A/W
		λ=λρ	0.85	1	-	0.85	1	-	
Dark current	ID	VR=5 V	-	0.1	0.8	-	0.8	4	nA
Dark current temperature coefficient	ΔTid		-	1.09	-	-	1.09	-	times/°C
Cutoff frequency	fc	VR=5 V, RL=50 Ω	300	600	-	25	60	-	MHz
Terminal capacitance	Ct	VR=5 V, f=1 MHz	-	5	8	-	55	120	pF
Shunt resistance	Rsh	VR=10 mV	100	700	-	25	125	-	ΜΩ
Detectivity	D*	λ=λρ	$1.5 \times 10^{12}$	$5 \times 10^{12}$	-	$1.5 \times 10^{12}$	$5 \times 10^{12}$	-	cm·Hz <sup>1/2</sup> /W
Noise equivalent power	NEP	λ=λρ	-	$5 \times 10^{-15}$	$2 \times 10^{-14}$	-	$1.4 \times 10^{-14}$	$4 \times 10^{-14}$	W/Hz <sup>1/2</sup>


# - Spectral response




# **Photosensitivity temperature characteristics**




#### Dark current vs. reverse voltage




#### - Terminal capacitance vs. reverse voltage



#### Linearity




# **►** Dark current vs. ambient temperature



KIRDB0621EA

Temperature (°C)

#### - Recommended solder reflow conditions




Time

- After unpacking, store the device in an environment at a temperature range of 5 to 30 °C and a humidity of 60% or less, and perform reflow soldering within 1 year.
- Therminal stress applied to the device during reflow soldering differs depending on the PC board and reflow oven being used.
- · When setting the reflow conditions, make sure that the reflow soldering process does not degrade device reliability.

KIRDB0622EA


# - Dimensional outlines (unit: mm)



Recommended land pattern

KIRDA0251E





#### Related information

www.hamamatsu.com/sp/ssd/doc\_en.html

- Precautions
- · Disclaimer
- Safety consideration
- · Surface mount type products
- Technical information
- · Infrared detector

Information described in this material is current as of September 2017.

Product specifications are subject to change without prior notice due to improvements or other reasons. This document has been carefully prepared and the information contained is believed to be accurate. In rare cases, however, there may be inaccuracies such as text errors. Before using these products, always contact us for the delivery specification sheet to check the latest specifications.

The product warranty is valid for one year after delivery and is limited to product repair or replacement for defects discovered and reported to us within that one year period. However, even if within the warranty period we accept absolutely no liability for any loss caused by natural disasters or improper product use. Copying or reprinting the contents described in this material in whole or in part is prohibited without our prior permission.

# **HAMAMATSU**

www.hamamatsu.com

HAMAMATSU PHOTONICS K.K., Solid State Division

1126-1 Ichino-cho, Higashi-ku, Hamamatsu City, 435-8558 Japan, Telephone: (81) 53-434-3311, Fax: (81) 53-434-5184

U.S.A.: Hamamatsu Corporation: 360 Foothill Road, Bridgewater, N.J. 08807, U.S.A., Telephone: (1) 908-231-0960, Fax: (1) 908-231-1218

Germany: Hamamatsu Photonics Deutschland GmbH: Arzbergerstr. 10, D-82211 Herrsching am Ammersee, Germany, Telephone: (49) 8152-375-0, Fax: (49) 8152-265-8

France: Hamamatsu Photonics France S.A.R.L.: 19, Rue du Saule Trapup, Parc du Moulin de Massy, 91882 Massy Cedex, France, Telephone: 33-(1) 69 53 71 00, Fax: 33-(1) 69 53 71 00

United Kingdom: Hamamatsu Photonics UK Limited: 2 Howard Court, 10 Tewin Road, Welwyn Garden City, Hertfordshire AL7 1BW, United Kingdom, Telephone: (44) 1707-294888, Fax: (44) 1707-325777

North Europe: Hamamatsu Photonics Norden AB: Torshamnsgatan 35 16440 Kista, Sweden, Telephone: (46) 8-509-031-00, Fax: (46) 8-509-031-01

Italy: Hamamatsu Photonics Italia S.r.l.: Strada della Moia, 1 int. 6, 20020 Arese (Milano), Italy, Telephone: (39) 02-93581733, Fax: (39) 02-93581741

China: Hamamatsu Photonics (China) Co., Ltd.: B1201, Jiaming Center, No.27 Dongsanhuan Beilu, Chaoyang District, Beijing 100020, China, Telephone: (86) 10-6586-6006, Fax: (86) 10-6586-6006, Fax: (86) 10-6586-6006.